



Adapter/Power Cable List

CURRENT PRODUCTS

Model	EU Adapter	UK Adapter	US Adapter
Adventurer (AX)	46001731 + 46001779	46001731 + 46001779	46001731 + 46001776
Aviator 2000 (A21P)	30035773	30035774	30035772
Aviator 5000 (A51)	46001802 + 46001779	46001802 + 46001779	46001802 + 46001776
Aviator 7000 (A71)	46001802 + 46001779	46001802 + 46001779	46001802 + 46001776
Catapult 1000 (C11)	46001724 + 46001779	46001724 + 46001779	46001724 + 46001776
Catapult 5000 (C51)	46001802 + 46001779	46001802 + 46001779	46001802 + 46001776
CL Series	46001724 + 46001779	46001724 + 46001779	46001724 + 46001776
CS Series	46001724 + 46001779	46001724 + 46001779	46001724 + 46001776
Defender 2000 (T22M)	46001802 + 46001779	46001802 + 46001779	46001802 + 46001776
Defender 2000 (T24P)	46001802 + 46001779	46001802 + 46001779	46001802 + 46001776
Defender 3000 (T31P, T32M)	46001802 + 46001779	46001802 + 46001779	46001802 + 46001776
Defender 3000 (T32XW)	72200234	72200236	72200237
Defender 5000 (TD52P)	72200229	72200231	72200232
Defender 5000 (TD52XW)	30379660	30379658	30379661
Defender 7000 (T72XW)	30132172	30132174	30132173
Defender 8000 (T82XW)	30325755	30325754	N/A
Explorer (EX) Precision & Analytical	46001884 + 83020940	46001884 + 83020939	46001884 + 83020938
Explorer (EX) High Capacity	30041419 + 30041462	30041419 + 30041464	30041419 + 30041267
Ioniser 100A			
JE Series (Emerald)	2 x AAA batteries	2 x AAA batteries	2 x AAA batteries
MB23 / MB25 / MB27	87925	89405	88668
MB90 / MB120	12120761	12120312	12120762
MC2000	4 x AA Batteries	4 x AA Batteries	4 x AA Batteries
Navigator (NV / NVL / NVT)	46001724 + 46001779	46001724 + 46001779	46001724 + 46001776
Pioneer (PX / PJX)	46001724 + 46001779	46001724 + 46001779	46001724 + 46001776
Ranger 1000 (R1000 / RC1000)	46001812 + 46001779	46001812 + 46001779	46001812 + 46001776
Ranger 2000 (R2000 / RC2000)	72200229	72200231	72200232
Ranger 3000 (R3000 / RC3000)	72200229	72200231	72200232
Ranger 4000 (R4000 / RC4000)	83020940	83020939	83020938
Ranger 7000 (R7000)	30041419 + 30041462	30041419 + 30041464	30041419 + 30041267
RU Series	71209768	72141528	-
Scout (SJX / SKX / SPX / STX)	30333866	30333867	30330714
SF40A Printer	11107909 + 12120761	11107909 + 12120312	11107909 + 12120762
Skipper 5000 (S51)			

For additional assistance please contact tsc@ohaus.com

TW2018R1

Part numbers are subject to change without notice



Adapter/Power Cable List

Skipper 6000 (S61)			
Skipper 7000 (S71)			
STP103 Printer	80252035 + 00087925	80252035 + 00089405	80252035 + 00088668
T4 Printer			
Traveler (TA / TAJ)	46001724 + 46001779	46001724 + 46001779	46001724 + 46001776
Valor 1000 (V11)	46001812 + 46001779	46001812 + 46001779	46001812 + 46001776
Valor 1500 (V15)	46001724 + 46001779	46001724 + 46001779	46001724 + 46001776
Valor 2000 (V22)	46001802 + 46001779	46001802 + 46001779	46001802 + 46001776
Valor 3000 (V31)	46001803 + 46001779	46001803 + 46001779	46001803 + 46001776
Valor 4000 (V41)	46001802 + 46001779	46001802 + 46001779	46001802 + 46001776
Valor 7000 (V71)	72200229	72200231	72200232
YA Series	2 x AAA Batteries	2 x AAA Batteries	2 x AAA Batteries

OBSOLETE PRODUCTS

Model	EU Adapter	UK Adapter	US Adapter
Adventurer (AR)	46001724 + 46001779	46001724 + 46001779	46001724 + 46001776
Adventurer (SL)	46001724 + 46001779	46001724 + 46001779	46001724 + 46001776
Adventurer Pro (AV)	46001724 + 46001779	46001724 + 46001779	46001724 + 46001776
AP Series	87925	89405	88668
AS Series	80500138 (obsolete)	80500139 (obsolete)	80500137 (obsolete)
AS142 Printer	46001724 + 46001779	46001724 + 46001779	46001724 + 46001776
Aviator 3000 (A31P)			
Aviator 3000 (A32P)	46001802 + 46001779	46001802 + 46001779	46001802 + 46001776
BC	Snr < 8033071417	Snr < 8033071417	Snr < 8033071417
	80120001 (obsolete)	80120002 (obsolete)	80120000 (obsolete)
	Snr > 8033071417:	Snr > 8033071417:	Snr > 8033071417:
	46001812 + 46001779	46001812 + 46001779	46001812 + 46001776
Brainweigh	87925	89405	88668
BW Series	46001810 + 46001779	46001810 + 46001779	46001810 + 46001776
C Series (Port-O-Gram)	46001724 + 46001779	46001724 + 46001779	46001724 + 46001776
CBM910 Printer	80252038	-	-
CD1	46001724 + 46001779	46001724 + 46001779	46001724 + 46001776
CD11	46001802 + 46001779	46001802 + 46001779	46001802 + 46001776
CD31 / CD33	46001802 + 46001779	46001802 + 46001779	46001802 + 46001776
CKW Series	71172177	71172930	71209118
CS Series (Grey)	80500458 (obsolete)	80500459 (obsolete)	80500457 (obsolete)
CT	46001724 + 46001779	46001724 + 46001779	46001724 + 46001776

For additional assistance please contact tsc@ohaus.com

TW2018R1

Part numbers are subject to change without notice



Adapter/Power Cable List

CW11	71134043	71134148	71134042
DA / DC / DP	21250113 (obsolete)	21250114 (obsolete)	21250115 (obsolete)
Defender 2000 (T21P)	46001812 + 46001779	46001812 + 46001779	46001812 + 46001776
Defender 2000 (T23P)	46001802 + 46001779	46001802 + 46001779	46001802 + 46001776
Defender 3000 (T31XW)	72200234	72200236	72200237
Defender 5000 (T51P)	72200229	72200231	72200232
Defender 5000 (T51XW)	72200234	72200236	72200237
Defender 7000 (T71P)	72200229	72200231	72200232
Defender 7000 (T71XW)	72200234	72200236	72200237
Diamond (JDxxxx)	46001724 + 46001779	46001724 + 46001779	46001724 + 46001776
Discovery	30006112 + 00087925	30006112 + 00089405	30006112 + 83020938
DS Series	80500150 (obsolete)	80500151 (obsolete)	N/A (obsolete)
E Series	80500138 (obsolete)	80500139 (obsolete)	80500137 (obsolete)
EB / EC Series	Snr < 8033071417	Snr < 8033071417	Snr < 8033071417
	80120001 (obsolete)	80120002 (obsolete)	80120000 (obsolete)
	Snr > 8033071417:	Snr > 8033071417:	Snr > 8033071417:
	46001812 + 46001779	46001812 + 46001779	46001812 + 46001776
ES Series	46001724 + 46001779	46001724 + 46001779	46001724 + 46001776
Explorer / Explorer Pro	30006112 + 00087925	30006112 + 00089405	30006112 + 83020938
FD Series	46001802 + 46001779	46001802 + 46001779	46001802 + 46001776
G Series	87925	89405	88668
GA Series	87925	89405	88668
GT Series	87925	89405	88668
HS / HP / HH	2 x AAA batteries	2 x AAA batteries	2 x AAA batteries
I5S Indicator	80500061 (obsolete)	80500062 (obsolete)	-
I10 / I20 / I20W Indicator	80500056 (obsolete)	80500057 (obsolete)	80500055 (obsolete)
I150 Indicator	87925	00089405 (obsolete)	88668
JR Series	80500138 (obsolete)	80500139 (obsolete)	80500137 (obsolete)
JS Series	46001724 + 46001779	46001724 + 46001779	46001724 + 46001776
LS Series	46001724 + 46001779	46001724 + 46001779	46001724 + 46001776
Mariner (MD)	46001802 + 46001779	46001802 + 46001779	46001802 + 46001776
MB35 / MB45	87925	89405	88668
MB200	87925	89405	88668
MB300 / MB301	87925	89405	88668
Mentor (Adventurer AR)	46001724 + 46001779	46001724 + 46001779	46001724 + 46001776
Navigator (Old)	46001724 + 46001779	46001724 + 46001779	46001724 + 46001776
Lume-O-Gram	9V, 150mA Adapter	9V, 150mA Adapter	9V, 150mA Adapter

For additional assistance please contact tsc@ohaus.com

TW2018R1

Part numbers are subject to change without notice



Adapter/Power Cable List

Pioneer Series (PA / PAJ / PA Plus)	46001724 + 46001779	46001724 + 46001779	46001724 + 46001776
PBI Series	87925	89405	88668
PS Series	00086320 (Batteries)	00086320 (Batteries)	00086320 (Batteries)
Ranger RC / RD / RP (No Battery)	22011363	22011365	22011364
Ranger RC / RD / RP (With Battery)	22011300 + 00209918	22011300 + 22005261	22011300 + 00208835
RA Series	46001802 + 46001779	46001802 + 46001779	46001802 + 46001776
RE Series	46001802 + 46001779	46001802 + 46001779	46001802 + 46001776
RH Series	87925	89405	88668
RI Series	87925	89405	88668
RS Series	71209768	72141528	-
RV Series	46001802 + 46001779	46001802 + 46001779	46001802 + 46001776
RZ Series	87925	N/A	N/A
Ruby	46001724 + 46001779	46001724 + 46001779	46001724 + 46001776
S200	46001724 + 46001779	46001724 + 46001779	46001724 + 46001776
Scout / Scout II	46001724 + 46001779	46001724 + 46001779	46001724 + 46001776
Scout Pro SPU / SPJ	46001724 + 46001779	46001724 + 46001779	46001724 + 46001776
SD Series	46001724 + 46001779	46001724 + 46001779	46001724 + 46001776
SF42 Printer	46001724 + 46001779	46001724 + 46001779	46001724 + 46001776
SRP275 Printer	80252034 + 00087925	80252034 + 00089405	80252034 + 00088668
TP Series	80500138 (obsolete)	80500139 (obsolete)	80500137 (obsolete)
Trooper (TR / TC)	46001802 + 46001779	46001802 + 46001779	46001802 + 46001776
TS Series	80500138 (obsolete)	80500139 (obsolete)	80500137 (obsolete)
UK149 Printer	80500208 (obsolete)	80500207 (obsolete)	N/A (obsolete)
Valor 1000 (V11PW)	46001812 + 46001779	46001812 + 46001779	46001812 + 46001776
Valor 2000 (V21)	46001802 + 46001779	46001802 + 46001779	46001802 + 46001776
Valor 5000 (V51)	46001802 + 46001779	46001802 + 46001779	46001802 + 46001776
Voyager / Voyager Pro	30006112 + 00087925	30006112 + 00089405	30006112 + 83020938
YJ Series	80251915	80251917	80251906
YS Series	80251915	80251917	80151906



Adapter/Power Cable List

Universal Adapters

30330714		
30333866		
30333867		
46001724	Adapter, Universal, 100-240V, 6W, 12V, 500mA,	Straight Tip (Old 420mA)
46001731	Adapter, Universal, 100-240V,	
46001802	Adapter, Universal, 100-240V, 10W, 12V, 840mA,	Straight Tip
46001803	Adapter, Universal, 100-240V, 10W, 12V, 840mA,	Right Angle Tip
46001810	Adapter, Universal, 100-240V, 10W, 9V, 1120mA,	Straight Tip
46001812	Adapter, Universal, 100-240V, 10W, 12V, 840mA,	Right Angle Tip
46001884	Adapter, Universal, 100-240V, 18W, 12V, 1500mA,	Straight Tip

Plugs & Plug Sets

46001779	Plug Set (EU, GB)
46001780	Plug Set (EU, GB, AU, US) Internal Use Only

Plugs

46001774	Plug (EU) Internal Use Only
46001775	Plug (AU)
46001776	Plug (US)
46001777	Plug (UK) Internal Use Only